

SANITIZING NEUTRAL DETERGENT FOR WOOD WINDOW FRAMES AND SHUTTERS - FAST CLEANER

Sanitizing ready-to-use neutral detergent suitable for cleaning painted window frames and shutters.

INTENDED USES

Wood frames, shutters, fences, balconies, doors, and other wood items located outdoors.

APPLICATION

- Apply FAST CLEANER and rub dry with a microfiber cloth until the product has been completely absorbed.
-



Exterior and interior use



Ready to use



Application with a cloth



Mechanical removal of germs and bacteria

CHEMICAL/PHYSICAL CHARACTERISTICS

Specific weight: 1.0 ±0.05 g/ml

WARNINGS

It removes germs and bacteria mechanically; it is not a disinfectant.

Keep from freezing. Store at temperatures between 5°C and 35°C.

If medical advice is needed, have a product container or label at hand.

Keep out of reach of children.

Dispose of contents and container in accordance with local, regional and international regulations.

SAFETY RECOMMENDATIONS

Consult the product's safety data sheet (SDS), which can be downloaded from the website

www.icaforyou.com.

The user must first ensure the suitability of the product for the specific intended use. We accept no responsibility for the outcome of the processing operations. The information contained on this data sheet, and any verbal information that may be provided, is supplied to the best of our knowledge. No liability is accepted for obsolete or incorrect information. The information on this data sheet is rendered obsolete upon publication of a new edition. Contact us to receive the latest edition or download it from the website www.icaforyou.com.
